

*Official copies of these procedures are maintained at this website.  
Before using a printed copy, verify that it is the most current  
version by checking the document issue date on this website. Signed  
copies of these official procedures are maintained at the Training Office.*

## C-A OPERATIONS PROCEDURES MANUAL

### ATTACHMENT

#### 4.100.a Roof Access Requirements

C-A-OPM Procedures in which this Attachment is used.		
4.100		

#### Hand Processed Changes

<u>HPC No.</u>	<u>Date</u>	<u>Page Nos.</u>	<u>Initials</u>
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____
_____	_____	_____	_____

Approved: \_\_\_\_\_ **Signature On File** \_\_\_\_\_  
 Collider-Accelerator Department Chairman      Date

A. Etkin

## ROOF ACCESS REQUIREMENTS

Building	Access Control	RHIC Operational	RHIC Non-Operational
1002A	Locked Fence	RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1002B	Locked Fence  Locked Ladder	Disable Beam in RHIC as per CAS RHICBERM.ACC berm fenced area access procedure.	Work Planning/ Work Permit
1002C		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1002D		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1004A	Locked Fence	RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1004B		Work Planning/ Work Permit	Work Planning/ Work Permit
1005E		Work Planning/ Work Permit	Work Planning/ Work Permit
1005H		Work Planning/ Work Permit	Work Planning/ Work Permit
1005P		Work Planning/ Work Permit	Work Planning/ Work Permit
1005R		Work Planning/ Work Permit	Work Planning/ Work Permit
1005S		Work Planning/ Work Permit	Work Planning/ Work Permit

1006- Assembly Building Section	Berm Fence  Locked Ladder	Disable Beam in RHIC as per CAS RHICBERM.ACC berm fenced area access procedure.	Work Planning/ Work Permit
1006A	Locked Fence	RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1006B		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1006C		Work Planning/ Work Permit	Work Planning/ Work Permit
1006D		Work Planning/ Work Permit	Work Planning/ Work Permit
1007W		Work Planning/ Work Permit	Work Planning/ Work Permit
1008 – Assembly Building Section	Berm Fence  Locked Ladder	Disable Beam in RHIC as per CAS RHICBERM.ACC berm fenced area access procedure.	Work Planning/ Work Permit
1008A	Locked Fence	RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1008A – Counting House	Locked Fence  Locked Ladder	Disable Beam in RHIC as per CAS RHICBERM.ACC berm fenced area access procedure.	Work Planning/ Work Permit
1008B		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1008C		RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1008D		Work Planning/ Work Permit	Work Planning/ Work Permit
1008E		RW-1, TLD and CAS supervision of Access with	Work Planning/ Work Permit

		Work Planning/ Work Permit	
1010A	Locked Ladder	RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1010B		Work Planning/ Work Permit	Work Planning/ Work Permit
1012A	Locked Fence  Locked Ladder	(Beam must be disabled for access to ladder) RW-1, TLD and CAS supervision of Access with Work Planning/ Work Permit	Work Planning/ Work Permit
1101		Work Planning/ Work Permit	Work Planning/ Work Permit